



● Structure Chart




No.	Parts	Material
1	bottom casing	STS304
2	plug	STS304
3	bearing	T/C
4	impeller	STS304
5	shaft	STS304
6	outlet chamber	STS304
7	mechanical seal	—
8	motor	—
9	base	Q235
10	tie rod	45#
11	diffuser	STS304
12	spacer	STS304
13	support diffuser	STS304

• DHF(T)1、2、3、4、5 Exploded View



- | | | |
|---|---------------------|-------------------|
| 1.Plug Body | 11.Seal Ring | 21.Outlet Chamber |
| 2.O-Ring | 12.Seal Ring Cover | 22.Rivet 2x6 |
| 3.Inlet Chamber | 13.Impeller | 23.Name Plate |
| 4.Hex Socket Head Cap Screw M8x16 | 14.Bearing Cone | 24.Motor |
| 5.Washer 8 | 15.Spacer | 25.Base |
| 6.Rod | 16.Support Diffuser | 26.Foot Support |
| 7.Seal Gasket | 17.Spacer | 27.Washer |
| 8.Non-metallic inserts Hex nuts M8 | 18.Diffuser | 28.Nuts |
| 9.Double stacked self-locking washers 8 | 19.Adjusting Pad | |
| 10.Compression Washer | 20.Mechanical Seal | |

• DHF(T)10、15、20 Exploded View



- | | | |
|---|---|--------------------|
| 1.Plug Body | 11.Seal Ring Cover | 21.Adjusting Pad |
| 2.O-Ring | 12a.Ring (DHF(T)10 Without this part) | 22.Mechanical Seal |
| 3.Inlet Chamber | 12.Impeller | 23.Outlet Chamber |
| 4.Hex Socket Head Cap Screw M8x16 | 13.Spacer | 24.Rivet 2x6 |
| 5.Washer 8 | 14.Bearing Cone | 25.Name Plate |
| 6.Rod | 15.Spacer | 26.Motor |
| 7.Non-metallic Inserts Hex Nuts M8 | 16.Seal Gasket B | 27.Base |
| 8.Double stacked self-locking washers 8 | 17.Support Diffuser | 28.Foot Support |
| 9.Compression Washer | 18.Seal Gasket A | 29.Washer |
| 10.Seal Ring | 19.Spacer | 30.Nuts |
| | 20.Diffuser | |